








ASSEMBLY INSTRUCTION

ITEM: 7050-90651-02 5/0 Upholstered Headboard
 7050-90652-02 5/0 Footboard
 7050-90667-02 6/0-6/6 Upholstered Headboard
 7050-90668-02 6/0-6/6 Footboard
 7050-90653-02 5/0-6/6 Rails
 7050-90663-02 6/0 Rails
 7050-90651-89 5/0 Upholstered Headboard
 7050-90652-89 5/0 Footboard
 7050-90667-89 6/0-6/6 Upholstered Headboard
 7050-90668-89 6/0-6/6 Footboard
 7050-90653-89 5/0-6/6 Rails
 7050-90663-89 6/0 Rails

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
 Read all instruction and study the drawing carefully before starting the assembly process.

HARDWARE PACK				
NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Open Wrench	3/8"	1 PC
B		Nut	3/8"	8 PCS
C		Curved Washer	3/8"	8 PCS
D		Threaded Rod	3/8*100mm	8 PCS
E		Screw	8*32mm	16 PCS (For 5/0 Bed) 20 PCS (For 6/6 & 6/0 Beds)

PARTS LIST			
NO.	DRAWING	DESCRIPTION	Q'TY
1		Headboard	1 PC
2		Rail	2 PCS
3		Footboard	1 PC
4		Slat	4 PCS (For 5/0 Bed) 5 PCS (For 6/6 & 6/0 Beds)
5		Support Leg	4 PCS (For 5/0 Bed) 5 PCS (For 6/6 & 6/0 Beds)
6		Footboard Middle Post	2 PCS
7		Footboard Top Post	2 PCS

Step 1: Attach Rails (2) to Headboard (1) and Footboard (3) by using Threaded Rods (D), Curved Washers (C) and Nuts (B), tighten them with Open Wrench (A) .

Step 2: Attach Support Legs (5) to Slats (4).

Step 3: Attach Slats (4) to the Rails (2) and tighten them by using Phillips head screwdriver.

Step 4: Install Footboard Middle Post (6) in clockwise direction into the bottom of the Footboard (3). Remove them by the reverse way.

Step 5: Install Footboard Top Post (7) in clockwise direction into the bottom of the Footboard Middle Post (6). Remove them by the reverse way.

ASSEMBLY INSTRUCTION

ITEM: 7050-90651-02 5/0 Upholstered Headboard
 7050-90652-02 5/0 Footboard
 7050-90667-02 6/0-6/6 Upholstered Headboard
 7050-90668-02 6/0-6/6 Footboard
 7050-90653-02 5/0-6/6 Rails
 7050-90663-02 6/0 Rails
 7050-90651-89 5/0 Upholstered Headboard
 7050-90652-89 5/0 Footboard
 7050-90667-89 6/0-6/6 Upholstered Headboard
 7050-90668-89 6/0-6/6 Footboard
 7050-90653-89 5/0-6/6 Rails
 7050-90663-89 6/0 Rails

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.
 Read all instruction and study the drawing carefully before starting the assembly process.

