



H O O K E R
— F U R N I T U R E —

ASSEMBLY INSTRUCTION

Item: 5183-75400 Upholstered Arm Chair

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

| NO | DRAWING | DESCRIPTION | SIZE | Q'ty |
|----|---------|-------------|-----------------|-------|
| A | | SCREW | 8# × 1-1/4" | 2pcs |
| B | | BOLT | Ø5/16" × 1-3/4" | 3pcs |
| C | | BOLT | Ø5/16" × 3-1/2" | 4pcs |
| D | | BOLT | Ø5/16" × 12" | 4pcs |
| E | | FLAT WASHER | Ø5/16" × 19 × 2 | 11pcs |
| F | | LOCK WASHER | Ø5/16" × 12 × 3 | 11pcs |
| G | | Wrench | 12mm | 1pc |

