

SHOWER ARM WITH FLANGE

Installation Instructions:

1. To remove old shower arm place strap wrench around arm and turn counter-clockwise.
2. Apply pipe joint compound or PTFE tape to new shower arm threads and thread into fitting in wall.
3. Using a strap wrench, turn arm clockwise until straight and tight.

NOTE: Using strap wrench to remove old shower arm, and install new arm will prevent marring of the finish. If using pipe wrench or pliers, be sure to wrap a rag around shower arm to protect the finish.

BRAZO DE REGADERA CON REBORDE

Instrucciones de Instalación:

1. Para sacar el brazo de ducha existente coloque la correa de la llave alrededor del brazo y gire en sentido antihorario.
2. Aplicar un sellante de roscas o cinta PTFE en los filetes de la rosca del brazo nuevo y enroscarlo en el tubo de la pared.
3. Con una llave para tubos de correa, gire el brazo en sentido de las manecillas de reloj hasta que esté derecho y ajustado.

NOTA: El uso de una llave para tubos de correa evita dañar el acabado de la superficie del brazo de la ducha. En caso de utilizar una llave común o pinzas para extraer el brazo de ducha colocar un pedazo de tela sobre la superficie de contacto para no dañar el terminado.

