



The application of acrylic floor polish provides a wear coating that protects flooring substrates from undue wear and damage, extending the life of the flooring system.



### People

- Team Assignments – 1 to 2 people.
- Safety Equipment – Please refer to product Safety Data Sheets. Wet Floor Signs
- Pre-Training: Since floor finish application is performed at a very low frequency and can involve the moving of heavy furniture, it is important to review the proper procedures and safety measures before proceeding with this maintenance activity.



### Product & Equipment

- Trident Flat Mop Frame
- Trident Finish Bucket (Optional)
- Blue Stripped Flat Mop Finish Pad
- Preferred Hillyard Finish / Seal
- Wet Floor Signs



### Procedures - Pour and Stick Method

1. Place wet floor signs in appropriate positions.
2. Pour Hillyard floor polish / seal of choice directly on the floor or into a container that makes application to the floor easier in a straight line about 10-15 linear feet in length.
3. Using a microfiber flat mop saturate the mop with product and then pass through the well dragging the polish away from the well and then pass the microfiber mop back through the previous pass.
4. Move the mop down 12-inches and repeat in a fresh area of finish. Apply new well of product as necessary making sure that a wet edge is maintained.
5. After entire area is coated, let dry 45 min.
6. Apply additional coats in the same manner listed above. Do not apply more than three coats in a single day. Allow last coat to dry 4-6 hours (preferably overnight) before opening area to traffic.  
**(TEMPERATURE AND HUMIDITY CONDITIONS AFFECT CURING TIME)**

**NOTE:** Proper curing between coats prevents pulling or streaking. Best results are obtained with adequate ventilation and floor temperatures above 60F.



Fresh Start  
3-5 Years



Protect  
Daily



Maintain  
Weekly



Revitalize  
Annually



### Procedures - Finish Bucket Method

1. Place wet floor signs in appropriate positions.
2. Pour Hillyard floor polish / seal of choice in Trident finish bucket. Place finish pad on microfiber frame / handle and dip into floor finish reservoir. Use the top grate to tap out excess finish.
3. Use the applicator to apply finish in a "U" shape on the floor, outlining 100 – 150 sq. ft. of flooring.
4. Recharge the finish head in the finish bucket, tap to remove excess finish, then use the application in a linear back and forth motion to fill in the "U". Using about a 2-inch overlap on each pass, to ensure you do not create any skips on the floor.
5. Continue to look in 100 – 150 sq. ft. sections, keeping a workable wet edge as you apply finish / seal.
6. After entire area is coated, let dry 45 min.
7. Apply additional coats in the same manner listed above. Do not apply more than three coats in a single day. Allow last coat to dry 4-6 hours (preferably overnight) before opening area to traffic.  
**(TEMPERATURE AND HUMIDITY CONDITIONS AFFECT CURING TIME)**

**NOTE:** Proper curing between coats prevents pulling or streaking. Best results are obtained with adequate ventilation and floor temperatures above 60F.



Fresh Start  
3-5 Years



Protect  
Daily



Maintain  
Weekly



Revitalize  
Annually