


# Installation instructions for 2809 & 2909 Privacy Adaptors to suit 2800 & 2900 Series Leversets (Purchase leverset and tubular latch separately)


## Step 1.

- Fold template where indicated.
- Position template on door edge at desired latch height.
- Firmly hold template & mark latch height & 5 hole centres (4 off 9mm & 1 off 44mm) at required backset.
- Measure door thickness and mark centre.
- Drill 25mm latch hole.
- **Note:** it is important to drill this hole squarely.
- Drill Pilot holes - suggest 3mm, then enlarge (4 off) 9mm holes & (1 off) 44mm holes from both sides of door.



## Step 2.

- Mark and chisel door edge for faceplate.
- Chisel the recess to a depth that allows latch to sit flush with door edge. Use latch faceplate as a template.
- Insert latch & fasten with wood screws provided.



## Step 3.


### Prepare Internal Assembly

- Remove rosette covers (1) from both lever assemblies.
- Remove alignment posts & tube nuts & discard.
- Hold the privacy adaptor (2) against the inside of internal lever-rosette (3) by inserting the adaptor's spindle extension (4) into square recess on inside of internal lever.
- Ensure that the privacy snib (5) is in the closed position.


**Note:** Emergency release arm must align with slot (7) on external lever-rosette assembly (8).

### Prepare External Assembly

- Install spring (9) into square recess (10) in external lever-rosette as shown.
- Insert emergency release bar (6) as shown locating L shaped end into slot (7).



**NOTE:** Carefully follow these instructions when installing. Screws to be tightened to a recommended 2.5Nm torque.



FOLD HERE

Mark centre-line of latch hole

Fit here on door edge

**Important Note**  
Drill 9mm holes before 44mm hole for ease of drilling

44mm hole

BACKSET 60mm

BACKSET 70mm

Fit here on door edge

9mm hole (drill first)



1800 098 094

info.au@allegion.com  
gainsboroughhardware.com.au

