

DO NOT fully tighten any of the bolts until the product is completely assembled, then put on a a flat surface to make sure the product is level and then fully tighten all the bolts.











