



DETAIL A

Installation Instructions

1. Horizontal Beam Assembly
 - a. Line up horizontal beam (2) holes with appropriate holes on vertical posts, and insert ¼" carriage bolts. Tighten washers and locknuts.
 - b. Repeat for second horizontal beam.
2. Bracket Mounting
 - a. Wall Attachment (as shown)
 - i. Pre-drill and tighten (2) lag screws into wall studs spaced 32" apart. Slide the assembled bracket through the keyholes and tighten it to the wall. Then pre-drill and tighten (2) lag screws into the bottom two holes.
 - b. Joist attachment (keyhole-shaped mounting holes)
 - i. Pre-drill and tighten (2) lag screws into the side of a 2x8 (or larger) floor joist spaced 32" apart. Slide the assembled bracket through the keyholes and tighten to the joist. Then pre-drill and tighten (2) lag screws into the middle two holes. (Detail A)
3. Attach the unit to the bracket
 - a. Use #10 self-tapping sheet metal screws to attach the mounting plate(s) to the horizontal beams (not supplied).
 - b. Hang boiler on mounting plates.

NOTE: Please adhere to all local laws and building codes.