



1. Mix thoroughly. Mix ratio is 100 parts by volume of Part A to 100 parts by volume of Part B. Mix for 2-3 minutes.

2. Apply to substrate. Apply to substrate with a brush, roller, or spray. Apply in a uniform layer.

3. Cure. Cure for 24 hours at 70°F (21°C). Cure for 72 hours at 50°F (10°C).

4. Re-coat. Re-coat after 24 hours.

5. Clean up. Clean up immediately with acetone.

6. Application. Apply to substrate with a brush, roller, or spray. Apply in a uniform layer.

7. Cure. Cure for 24 hours at 70°F (21°C). Cure for 72 hours at 50°F (10°C).

8. Re-coat. Re-coat after 24 hours.

9. Clean up. Clean up immediately with acetone.

10. Storage. Store in a cool, dry place.

11. Safety. Wear eye protection and gloves.

12. Disposal. Dispose of in accordance with local regulations.