

Helping You Wear it Right

Wearing your 3M™ Secure Click™ Full Facepiece Respirator
FF-800 Series



1. Fully loosen all six head straps. Hold the front of the facepiece with one hand and the straps/comfort cradle away from the facepiece with the other hand, creating an opening for the head.

Pull the respirator assembly down over the head. Place the nose in the nose cup and chin in the chin cup area then press the facepiece firmly and evenly against the face.



2. While holding the facepiece in place, pull the straps over your head.



3. Tighten the two bottom straps.



4. Tighten the two middle straps, then the two top straps. Make sure the back of the harness is centered on the back of the head and that the straps and tabs lay flat against your head.

Repeat steps 3 and 4 twice, once to position and second to secure the facepiece seal.

User Seal Check

Can be used with any 3M™ SecureClick™ Gas and Vapour Filters or Cartridges.



Lightly press the seal check button until you feel resistance. Hold the button in this position and exhale (blow out). If facepiece bulges slightly with no leaks detected between your face and the facepiece, a proper seal has been obtained.



If faceseal leakage is detected, reposition the respirator on your face and/or readjust the tension of the straps to eliminate the leakage and recheck seal.

Care must be taken when performing the positive pressure seal check not to exhale too hard. The aim is to check the seal, not disturb the seal between the mask and the face.

If you cannot achieve a proper fit, **do not** enter the contaminated area. See your supervisor.