

Standard POP Attachment Instructions



Attach standard POP 1.5"
from left side of unit along seam
ENGLISH SIDE OUT



Attach to seat pad seam
in the position shown above
with 2 swift tacks
9mm swift tacks