BUSCH® SYSTEMS

INSTALLATION INSTRUCTIONS

EVOLVE® CASTER KIT

PARTS INCLUDED:

2x Locking Casters
2x Non-Locking Casters

TOOLS REQUIRED:

1/2" Open-End Wrench
or Multi-Tool included with Magnet Kit



TIP: Install both Locking Casters towards the front of the container

PLEASE NOTE:

These casters are compatible with the Cube, Cube Slim, & Ellipse Configurations

STEP-BY-STEP INSTRUCTIONS


FIG. 1


FIG. 2


FIG. 3

1. Remove original feet from bottom of Evolve® body by turning foot counterclockwise until threaded shaft comes out of the insert. **FIG. 1**
2. Once all feet are removed from the inserts, take each Caster and align it's threaded shaft with the inserts, holding onto the bolt area and turning clockwise threading the Caster into the body by hand until snug. **FIG. 2**
3. Once each Caster is hand tightened, use a ½ inch Open-End Wrench or Busch Multi-Tool to tighten up each Caster bolt. Once you've tightened all Casters, install is complete. **FIG. 3**