

WHITMORE WOOD/UPH QUEEN PANEL BED

ASSEMBLY INSTRUCTIONS




PARTS PACKING CONFIGURATIONS

BOX #1

A. HEADBOARD

1 PC

**BOX #2**

B. FOOTBOARD


1 PC

C. SLAT ROLL

1 SET



D. SUPPORT LEG

5 PCS


**BOX #3**

E. SIDE RAIL

2 PCS

**FULLY ASSEMBLED****HARDWARE KIT PACKED IN BOX #2**


NO.	DESCRIPTION	IMAGE	QTY
1	THREADED BOLT (5/16"x80mm)		8 PCS
2	THREADED HALF MOON WASHER NUT (5/16")		8 PCS
3	WRENCH		1 PC
4	WOOD SCREW (4x30mm)		10 PCS
5	ALLEN KEY		1 PC

**STEP 1**


WHITMORE WOOD/UPH QUEEN PANEL BED ASSEMBLY INSTRUCTIONS



STEP 2




STEP 3



STOP

- IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4


STEP 4




WHITMORE WOOD/UPH QUEEN PANEL BED ASSEMBLY INSTRUCTIONS



STEP 5



STEP 6




WHITMORE WOOD/UPH QUEEN PANEL BED

ASSEMBLY INSTRUCTIONS



STEP 7



ASSEMBLY COMPLETE


PAGE 4 OF 5

INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support.

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the slat.



MAINTENANCE INSTRUCTIONS:

- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

WHITMORE WOOD/UPH QUEEN PANEL BED

ASSEMBLY INSTRUCTIONS

APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT



AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.

PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.


THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL : 1 SET
D. SUPPORT LEG : 5 PCS

4. WOOD SCREW (4x30mm): 10 PCS

STEP #1:

USE ALLEN KEY (5) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.







NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION

WHITMORE WOOD/UPH KING PANEL BED


ASSEMBLY INSTRUCTIONS



PARTS PACKING CONFIGURATIONS

BOX #1**A. HEADBOARD****1 PC****BOX #2****B. FOOTBOARD****1 PC****C. SLAT ROLL****1 SET****D. SUPPORT LEG****10 PCS****BOX #3****E. SIDE RAIL****2 PCS****FULLY ASSEMBLED****HARDWARE KIT PACKED IN BOX #2**


NO.	DESCRIPTION	IMAGE	QTY
1	THREADED BOLT (5/16"x80mm)		8 PCS
2	THREADED HALF MOON WASHER NUT (5/16")		8 PCS
3	WRENCH		1 PC
4	WOOD SCREW (4x30mm)		10 PCS
5	ALLEN KEY		1 PC

**STEP 1**


WHITMORE WOOD/UPH KING PANEL BED ASSEMBLY INSTRUCTIONS



STEP 2




STEP 3



STOP

- IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6 & 7 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4

STEP 4




WHITMORE WOOD/UPH KING PANEL BED


ASSEMBLY INSTRUCTIONS

MODUS
FURNITURE

STEP 5




STEP 6



WHITMORE WOOD/UPH KING PANEL BED ASSEMBLY INSTRUCTIONS



STEP 7



ASSEMBLY COMPLETE


PAGE 4 OF 5

INSTRUCTIONS FOR ADJUSTING LEVELERS:

Position the bed in your space and locate the leveler under each leg support.

Turn the leveler counter-clockwise to extend and clockwise to retract it.

Adjust each leveler until each leg support is applying equal, upward pressure on the slat.



MAINTENANCE INSTRUCTIONS:

- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

WHITMORE WOOD/UPH KING PANEL BED

ASSEMBLY INSTRUCTIONS

APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT



AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.
IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.


PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION.
FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.

THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL	: 1 SET	4. WOOD SCREW (4x30mm):	10 PCS
D. SUPPORT LEG	: 10 PCS		

STEP #1:

USE ALLEN KEY (5) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.



NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION

WHITMORE WOOD/UPH CAL KING PANEL BED

ASSEMBLY INSTRUCTIONS




PARTS PACKING CONFIGURATIONS

BOX #1

A. HEADBOARD

1 PC



BOX #2

B. FOOTBOARD


1 PC

C. SLAT ROLL

1 SET

D. SUPPORT LEG

10 PCS




BOX #3

E. SIDE RAIL


2 PCS

F. MATTRESS SPACER

2 PCS



FULLY ASSEMBLED



HARDWARE KIT PACKED IN BOX #2


NO.	DESCRIPTION	IMAGE	QTY
1	THREADED BOLT (5/16"x80mm)		8 PCS
2	THREADED HALF MOON WASHER NUT (5/16")		8 PCS
3	WRENCH		1 PC
4	WOOD SCREW (4x30mm)		10 PCS
5	ALLEN KEY		1 PC

HARDWARE KIT PACKED IN BOX #3

NO.	DESCRIPTION	IMAGE	QTY
6	ALLEN BOLT (1/4"x50mm)		12 PCS
7	SPRING WASHER (5/16")		12 PCS
8	FLAT WASHER (5/16")		12 PCS
9	ALLEN KEY		1 PC




STEP 1




WHITMORE WOOD/UPH CAL KING PANEL BED ASSEMBLY INSTRUCTIONS



STEP 2




STEP 3



STOP

- IF USING BED WITH AN ADJUSTABLE MATTRESS BASE, SKIP STEPS 4, 5, 6, 7 & 8 AND REFERENCE APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT.
- IF USING BED FRAME WITH STANDARD BOX SPRING OR FOUNDATION, CONTINUE TO STEP 4


STEP 4




WHITMORE WOOD/UPH CAL KING PANEL BED ASSEMBLY INSTRUCTIONS



STEP 5



STEP 6



A line drawing of a bed frame, viewed from an isometric perspective. The frame consists of a headboard with vertical slats, a footboard, and a base with several horizontal slats supported by vertical legs. The drawing is a simple line art illustration.

PAGE 4 OF 5

- Periodically check all fittings and tighten if necessary, as they can loosen over time.
- Always remove box spring and mattress before moving the bed.
- Lift the bed when moving it. Dragging the bed can damage the center support.
- Readjust levelers after moving the bed.

WHITMORE WOOD/UPH CAL KING PANEL BED

ASSEMBLY INSTRUCTIONS

APPENDIX A: ADJUSTABLE MATTRESS BASE ASSEMBLY SUPPLEMENT



AN ADJUSTABLE MATTRESS BASE IS A FREESTANDING MATTRESS SUPPORT THAT SITS WITHIN THE PERIMETER OF THE BED FRAME.

IF USING THIS BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION THESE INSTRUCTIONS DO NOT APPLY.


PRE-ASSEMBLED SIDE RAIL CLEATS OBSTRUCT ADJUSTABLE BASE INSTALLATION AND OPERATION. FOLLOW THESE INSTRUCTIONS TO REMOVE THEM.

THE FOLLOWING PARTS ARE NOT REQUIRED FOR ADJUSTABLE MATTRESS BASE INSTALLATION:

C. SLAT ROLL	: 1 SET	4. WOOD SCREW (4x30mm):	10 PCS
D. SUPPORT LEG	: 10 PCS	6.ALLEN BOLT (1/4"x50mm):	12 PCS
F. MATTRESS SPACER	: 2 PCS	7. SPRING WASHER (5/16"):	12 PCS
		8. FLAT WASHER (5/16"):	12 PCS

STEP #1:

USE ALLEN KEY (9) TO UNSCREW ALLEN BOLTS AND REMOVE PRE-ASSEMBLED SIDE RAIL CLEATS.



NOTE: YOU MAY WISH TO RETAIN UNUSED PARTS IF IN THE FUTURE YOU INTEND TO USE THE BED FRAME WITH A STANDARD BOX SPRING OR FOUNDATION