

CAUTION: Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.

P563001

WARNING - Follow the Instructions Carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a Qualified Electrical Contractor.

WARNING - Risk of fire or electrical shock.

WARNING - To comply with the National Electric Code and Underwriters Laboratories Requirements, when installed outdoors or in wet locations, the edge of the wall plate coming in contact with the mounting surface must be sealed with a latex waterproof caulking to prevent water from entering the outlet box.

NOTE - SUITABLE FOR WET LOCATIONS WHEN COVERS (H) ARE SECURELY INSTALLED FLUSH TO CYLINDER.

CANOPY MOUNTING & WIRE CONNECTION ASSEMBLY STEPS:

1. A → B, C
2. D → E
3. F → B
4. G → F, B

NOTE: ON UP/DOWN MODELS WIRING CAN BE WIRED TOGETHER OR CONTROLLED BY TWO SEPARATE SWITCHES

**C & E
 (NOT FURNISHED)
 (NO INCLUIDA)
 (NON FOURNIE)**

