

Assembly Instructions

B3941-070 SILVER SANDS CHEST

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the PARTS LIST and/or HARDWARE LIST shown below.

Caution: Please read the instructions thoroughly before assembly.


- 1. We recommend that you assemble this product with the assistance of another person: this will make the assembly easier, and will help eliminate damage to the product or injury to person during assembly.
- 2. Please do not over tighten screws or bolts until the assembly is completed.
- 3. Please put all parts on a non-abrasive floor befor assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST

NO:	COMPONENT	ADRAWING	Q'TY
Α	CHEST		1 PC
В	FOOT		4 PCS


STEP 1

Install the Wooden Dowel (1) into the blind hole on the Foot (B).




STEP 2


Assemble the Foot (B) to Chest (A) by using the Allen Key (5) with hardware 2, 3, and 4.



HARDWARE LIST

COMPONENT	ADRAWING	Q'TY
Wooden Dowel Ø10"x1-5/8"		4 PCS
Bolt Ø5/16"x2-3/8"		4 PCS
Lock Washer Ø5/16"	(5)	4 PCS
Flat Washer Ø5/16"x3/4"	0	4 PCS
Allen Key		1 PC
Anti-Tipping Kit	O	1 SET
	Wooden Dowel Ø10"x1-5/8" Bolt Ø5/16"x2-3/8" Lock Washer Ø5/16" Flat Washer Ø5/16"x3/4" Allen Key	Wooden Dowel Ø10"x1-5/8" Bolt Ø5/16"x2-3/8" Lock Washer Ø5/16" Flat Washer Ø5/16"x3/4" Allen Key





MADE IN VIETNAM