



Quality Gloves Since 1975

HANGTAG ASSEMBLY INSTRUCTIONS - ZIP-TIE APPLICATION (2 PAIR)

STEP 1:



Bend the bridge of the hangtag at both creases. Place the black hook through the hole in the bridge, with the “Kinco” logo facing the front of the hangtag.

STEP 2:



Place one pair of gloves together palm-to-palm, and insert a zip-tie through the center slits of the pull tabs.

STEP 3:



From the inside of the hangtag insert the zip-tie through the left hole of the black hook and hangtag (these holes should align).

Place the second pair of gloves palm-to-palm (behind the first pair, the hook, and hangtag) and insert the zip-tie through the slits in the pull-tabs of the second pair of gloves.

STEP 4:



Insert the zip-tie through the second hole in the hangtag and hook, and tighten and secure the zip-tie by pulling it through the end piece attaching all elements together.

STEP 5:



Trim off the excess zip-tie material using scissors and fold the front of the tag down. Caution: Do not trim zip-tie too close to end piece. Plastic pin the front of the hangtag to the top of the glove.

If required, plastic pin the front of the hangtag to the top of the glove and attach vanity tags.

FINISHED ASSEMBLY



Front view

Side view

Back view