



SA63 SPEAKER 1/2" + WALL THICKNESS INSTALLATION TECHNICAL NOTE

FOLLOW THESE BEST PRACTICES WHEN INSTALLING A SA63 FULL-RANGE SPEAKER IN WALL MATERIALS GREATER THAN 1/2" THICK

NOTE: Additional spacing must be added to ensure proper fitment.

1. The standard installation includes a 1/2" tall trim ring. For wall materials exceeding this thickness, calculate the additional depth required and install the appropriate number of SA-SP-0.125 spacer rings (1/8" thick) to compensate for the excess wall thickness.
 - Spacer rings should be stacked as needed and installed in conjunction with the trim ring
2. Longer mounting screws will also be required. James by Sonance stocks select screw lengths up to 2.5". Please contact James to confirm availability and appropriate sizing for your installation.