

# trueblue

bath waste

## Innovative, flexible and designed with the plumber in mind!

True Blue's integrated locking features reduce the amount of tools needed for installation which reduces frustration and time.

- Reusable test plugs install with a 1/4 turn and are approved for testing up to 40 ft. of head. Makes testing fast and reliable.
- Screw-less overflow faceplate is engineered for a high flow rate and to accommodate multiple tub wall thicknesses. Installed with a clockwise turn, the symmetrical design eliminates the need for perfect alignment.
- Locking drain gasket is designed with a softer durometer and will not fall off when installed at tricky angles. Reduces installation frustrations while creating a better seal.
- Foamed rubber overflow gasket provides better compression and memory, creating a better and more reliable seal to prevent leaks.
- Pre-assembled components make installation quicker so you can go from box to test faster.
- Press-in trim veneer for designer finishes installs simply with overflow test plug. Eliminates the need for additional tools or sealants.



BATH WASTE AND OVERFLOW

### Finishes Available:



Matte Black



White



Brushed Nickel



Oil-Rubbed Bronze



Chrome

### BATH WASTE AND OVERFLOW



#P9860BNPS shown



#A9950BNPS shown



#K97BNPS shown

#### True Blue Bath Waste - Finished Drain Spud Offering

- Kit variations include a finished drain spud versus a trim veneer for designer finishes.
- Drain spuds can accept a trim veneer for easy finish change and replacement.
- Available in brushed nickel, oil rubbed bronze, white & matte black.
- Same great features & benefits as existing True Blue items.

Product No.	Description	Ctn. Qty.
<b>Full Kits</b>		
A9840BNPS	ABS Full Kit, Push & Pull Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
A9840RBPS	ABS Full Kit, Push & Pull Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
A9850BNPS	ABS Full Kit, Touch Toe Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
A9850RBPS	ABS Full Kit, Touch Toe Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
A9860BNPS	ABS Full Kit, Uni-Lift Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
A9860RBPS	ABS Full Kit, Uni-Lift Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
P9840BNPS	PVC Full Kit, Push & Pull Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
P9840RBPS	PVC Full Kit, Push & Pull Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
P9850BNPS	PVC Full Kit, Touch Toe Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
P9850RBPS	PVC Full Kit, Touch Toe Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
P9860BNPS	PVC Full Kit, Uni-Lift Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
P9860RBPS	PVC Full Kit, Uni-Lift Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
<b>Half Kits</b>		
A9940BNPS	ABS Half Kit, Push & Pull Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
A9940RBPS	ABS Half Kit, Push & Pull Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
A9940WHPS	ABS Half Kit, Push & Pull Stopper, w/ Test Kit, White, Finished Drain Spud	10
A9940MBPS	ABS Half Kit, Push & Pull Stopper, w/ Test Kit, Matte Black, Finished Drain Spud	10
A9950BNPS	ABS Half Kit, Touch Toe Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
A9950RBPS	ABS Half Kit, Touch Toe Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
A9950WHPS	ABS Half Kit, Touch Toe Stopper, w/ Test Kit, White, Finished Drain Spud	10
A9950MBPS	ABS Half Kit, Touch Toe Stopper, w/ Test Kit, Matte Black, Finished Drain Spud	10
A9960BNPS	ABS Half Kit, Uni-Lift Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
A9960RBPS	ABS Half Kit, Uni-Lift Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
A9960WHPS	ABS Half Kit, Uni-Lift Stopper, w/ Test Kit, White, Finished Drain Spud	10
A9960MBPS	ABS Half Kit, Uni-Lift Stopper, w/ Test Kit, Matte Black, Finished Drain Spud	10
P9940BNPS	PVC Half Kit, Push & Pull Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
P9940RBPS	PVC Half Kit, Push & Pull Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
P9940WHPS	PVC Half Kit, Push & Pull Stopper, w/ Test Kit, White, Finished Drain Spud	10
P9940MBPS	PVC Half Kit, Push & Pull Stopper, w/ Test Kit, Matte Black, Finished Drain Spud	10
P9950BNPS	PVC Half Kit, Touch Toe Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
P9950RBPS	PVC Half Kit, Touch Toe Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
P9950WHPS	PVC Half Kit, Touch Toe Stopper, w/ Test Kit, White, Finished Drain Spud	10
P9950MBPS	PVC Half Kit, Touch Toe Stopper, w/ Test Kit, Matte Black, Finished Drain Spud	10
P9960BNPS	PVC Half Kit, Uni-Lift Stopper, w/ Test Kit, Brushed Nickel, Finished Drain Spud	10
P9960RBPS	PVC Half Kit, Uni-Lift Stopper, w/ Test Kit, Oil Rubbed Bronze, Finished Drain Spud	10
P9960WHPS	PVC Half Kit, Uni-Lift Stopper, w/ Test Kit, White, Finished Drain Spud	10
P9960MBPS	PVC Half Kit, Uni-Lift Stopper, w/ Test Kit, Matte Black, Finished Drain Spud	10
<b>Trim Kits</b>		
K97BNPS	Trim Kit, Touch Toe, Brushed Nickel, Finished Drain Spud	10
K97RBPS	Trim Kit, Touch Toe, Oil Rubbed Bronze, Finished Drain Spud	10
K97WHPS	Trim Kit, Touch Toe, White, Finished Drain Spud	10
K97MBPS	Trim Kit, Touch Toe, Matte Black, Finished Drain Spud	10
K98BNPS	Trim Kit, Uni-Lift, Brushed Nickel, Finished Drain Spud	10
K98RBPS	Trim Kit, Uni-Lift, Oil Rubbed Bronze, Finished Drain Spud	10
K98WHPS	Trim Kit, Uni-Lift, White, Finished Drain Spud	10
K98MBPS	Trim Kit, Uni-Lift, Matte Black, Finished Drain Spud	10
K99BNPS	Trim Kit, Push & Pull, Brushed Nickel, Finished Drain Spud	10
K99RBPS	Trim Kit, Push & Pull, Oil Rubbed Bronze, Finished Drain Spud	10
K99WHPS	Trim Kit, Push & Pull, White, Finished Drain Spud	10
K99MBPS	Trim Kit, Push & Pull, Matte Black, Finished Drain Spud	10