



Quality Gloves Since 1975

HANGTAG ASSEMBLY INSTRUCTIONS - PLASTIC PIN APPLICATION (MULTI-PACK)

STEP 1:



Bend the bridge of the hangtag at both creases, place the glove pairs together (right hand on top and left on bottom with palm-side out) and insert the back of the hangtag into the cuff of the left glove.

STEP 2:



Fold the front of the hangtag over the top glove, move the gloves to the top of the triangle opening at the top of the hangtag.
Note: Ensure that the gloves don't block the triangle hole.

STEP 3:



Insert the needle of the denison gun through the drill hole on the front of the hangtag, through the pairs of gloves, and through the drill hole on the back of the hangtag. Repeat for the second drill hole. Insert two plastic pins in each drill hole.

STEP 4:



Ensure two pins go through each drill hole and through both gloves so all parts are attached to one another.

FINISHED ASSEMBLY



Side view



Back view