

450mm

367mm
Cutout Dimensions

84mm
Cutout Dimensions

114mm

TOE KICK CUT-OUT TEMPLATE

1. Survey the surface to be cut to avoid wiring, pipes, and other obstructions that might interfere with the toe kick and PPX pipe.
2. Use this template to trace an outline in the desired PPX toe kick location, taking care for position and level.
3. Cut into the surface along the traced outline using a keyhole or drywall saw.
4. Proceed with PPX toe kick installation steps from the PPX PowerPipe Manual.

NOTE: See manual for detailed instructions at: www.sonance.com.

SONANCE | *James*

**TOE KICK TRIM FOR PPX POWERPIPE
GUIDE AND CUT-OUT TEMPLATE**



INSTALLATION GUIDE

1. Position PPX pipe and attached connector from inside the cabinet or surface and pull through the surface opening to make it flush to the baseboard/surface opening.
2. Loosely secure toe kick wall plate to toe kick connector opening from the front at the six screw points.
3. Secure plate to the baseboard/surface in four outermost corners.
4. Attach the magnetic toe kick grille to the installed toe kick plate.

©2025 Sonance All rights reserved. SONANCE 991 Calle Amanecer, San Clemente, CA 92673 USA • Phone: 949.492.7777 • www.sonance.com