



KIT INCLUDES:

- x1) Bag Wrangler
 - Includes holder & grommet, pre-assembled
- x2) Mounting Screws

TOOLS REQUIRED:

Robertson #2 Screwdriver



FIG. 1



FIG. 2



FIG. 3

STEP-BY-STEP INSTRUCTIONS

- 1 Locate the Mosaic unit you're wanting to mount a Bag Wrangler onto.
- 2 Remove lid. Determine what side of the Top Rim you'd like to mount the Bag Wrangler onto. **FIG. 1**
**Note – Bag Wrangler can only be mounted on the short axis as outlined.*
- 3 Place Bag Wrangler over holes in the Top Rim. Install (1) Mounting Screw into each of the Bag Wranglers exposed holes, locking the Bag Wrangler into place on the Top Rim. **FIG. 2**
- 4 Bag can now be inserted onto the Bag Hooks with any excess or bag slack being able to be secured through the Bag Wrangler. **FIG. 3**





FIG. 4



FIG. 5



FIG. 6

TO REMOVE A FILLED BAG:

- 1 Lift the circle of the Bag Wrangler upwards and pull the bag downwards through the Bag Wrangler and out of the grommet. **FIG. 4**
- 2 Once bag tie-off fully removed, detach the bag from each of the 4 x corner bag hooks and pull upwards. **FIG. 5**
- 3 The Mosaic can now have a new bag installed. **FIG. 6**

