

Assembly Instructions

**ITEM NO. B1424-110
TALCOTT - KING HEADBOARD**

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items and compare with the parts list and/or hardware list shown below.

Caution : please read the instruction thoroughly before assembly.


1. We recommended that you assemble this product with the assistance of another person, this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
2. Please do not tighten screws or bolt until the assembly is completed.
3. Please put all parts on a non-abrasive floor before assembly and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PARTS LIST			
NO.	DESCRIPTION	SKETCH	QTY
A	HEADBOARD		1 pc
B	RIGHT SIDE FACING (RSF) HEADBOARD LEG		1 pc
C	LEFT SIDE FACING (LSF) HEADBOARD LEG		1 pc
D	STRECHER		1 pc

HARDWARE LIST			
NO.	DESCRIPTION	SKETCH	QTY
1	JCBB - M8 x 1-9/16"		6 pcs
2	SPRING WASHER - M8		6 pcs
3	FLAT WASHER - M8 x 25/32"		6 pcs
4	ALLEN KEY - M5		1 pc
5	JCBC - M6 x 1-9/16"		4 pcs
6	SPRING WASHER - M6		4 pcs
7	FLAT WASHER - M6 x 16/32"		4 pcs
8	ALLEN KEY - M4		1 pc
9	AC/DC ADAPTER		1 pc

WEIGHT CAPACITY	800 lbs
-----------------	---------

STEP 1 : Assembly the RSF Headboard Leg (B) and LSF Headboard Leg (C) to the Headboard (A) by using Allen Key (4) with hardware 1, 2 and 3.



STEP 2 : Assembly the Stretcher (D) to the RSF Headboard Leg (B) and LSF Headboard Leg (C) by using Allen Key (8) with hardware 5, 6 and 7.

PLACE WOOD PART ON A
CLEAN NON-ABRASIVE SURFACE

