

HEKMAN®

X A HOWARD MILLER COMPANY

79305 /79306 RT/LT PIER BOOKCASE



Assembly Instruction

STEP 1

REMOVE THE BASE MOLDING AND MIDDLE MOLDING ON THE LEFT AND RIGHT SIDE OF THE CENTER BOOKCASE BY SLIDING THEM STRAIGHT BACK. THE RIGHT AND LEFT BOOKCASES SIT TIGHT AGAINST THE CENTER BOOKCASE.

