








# HEKMAN®

A HOWARD MILLER COMPANY

## 23564 ONE DRAWER NIGHTSTAND

### Hardware List

A	B	C	D	E	F	
ALLEN BOLT M6 X 50 (12 PCS.)	FLAT W. M6 12 PCS.	SPRING W. M6 12 PCS.	SCREW Ø8 X 1 1/4" (4 PCS.)	SCREW Ø6 X 1 1/4" (16 PCS.)	ALLEN KEY M4 (FOR ALLEN BOLT) 1 PC.	
						

### Assembly Instruction

#### STEP 1.

LAY TOP PANEL UPSIDE DOWN ON A SOFT, CLEAN AND FLAT SURFACE. REMOVE DRAWER.

#### STEP 2.

ATTACH END ASSEMBLY "X" TO BODY WITH (4) ALLEN BOLT "A", (4) FLAT WASHER "B" AND (4) SPRING WASHER "C" WITH ALLEN KEY "F".

#### STEP 3.

ASSEMBLY SHELF AND END ASSEMBLY "Y" TOGETHER. ATTACH END ASSEMBLY WITH (4) ALLEN BOLT "A", (4) FLAT WASHER "B" AND (4) SPRING WASHER "C" WITH ALLEN KEY "F". ATTACH SHELF TO POSTS WITH (4) WOOD SCREWS "D" (SCREW DRIVER NOT INCLUDED).

#### STEP 4.

ATTACH DUST PANEL WITH (16) WOOD SCREWS "E"  
NOTE: THERE IS A FRONT & BACK TO THE DUST PANEL.

#### STEP 5.

ALIGN HOLE IN BASE TO POST AND CONNECT USING FLAT WASHER (B), SPRING WASHER (C), ALLEN BOLT (A) AND ALLEN KEY (E) PROVIDED.

#### STEP 6.

SET NIGHT STAND UPRIGHT AND INSTALL DRAWER.