

QX SERIES INSTALLATION

1

MARK SPEAKER POSITION
using level and straight edge

2

SCORE DRYWALL
use straight edge and knife

3

CUT SPEAKER HOLE
use drywall saw

4

LOOSEN BRACKET SCREWS

5

REMOVE SPEAKER FROM FRAME

6

SECURE FRAME TO WALL

James

7



INSTALL SPEAKER INTO FRAME

8



SECURE SPEAKER TO FRAME

9



SEPARATE PERF GRILLE FROM GRILLE FRAME. PAINT PERF GRILLE IF REQUIRED

10



ONCE PERF GRILLE IS READY, REMOVE TAPE BACKING

11



CAREFULLY SECURE FRAME TO PERF GRILLE

12



INSTALL GRILLE TO SPEAKER. ENJOY!

James