



Quality Gloves Since 1975

HANGTAG ASSEMBLY INSTRUCTIONS - PLASTIC PIN APPLICATION (LINED GLOVE)

STEP 1:



Bend the bridge of the hangtag at both creases. Place the black hook through the hole in the bridge, with the "Kinco" logo facing the front of the hangtag.

STEP 2:



Place the hook and hangtag inbetween the gloves and place the denison gun through the front hem of back left-hand glove.

STEP 3:



Insert the denison gun needle through the round center hole in the hangtag and hook, and through the cuff of the front right-hand glove so all parts are securely attached using two plastic pins.

STEP 4:



Pin the front of the hangtag to the glove using the drill hole on the bottom right hand corner of the hangtag.

STEP 5:



Ensure all parts of the glove and hangtag are securely attached and the back cuff is open so the user can try on the glove.

FINISHED ASSEMBLY



Side view

Back view