

Processing Procedure Perfect Panel Curtains

PROCESSING REQUIREMENTS

Formula: This formula is only a guideline. Alterations should be made at the discretion of the laundry professional based on specific requirements, supplies, equipment and experience.

	OPERATION	TIME	WATER		SUPPLIES PER 100 LB. LOAD
			LEVEL	TEMP.	
1.	Flush	3 min.	High	100°F	--
2.	Break/Suds	8 min.	Low	140°F	6 oz. nonionic detergent & 6 oz. alkali
3.	Rinse	2 min.	High	140°F	--
4.	Rinse	2 min.	High	130°F	--
5.	Rinse	2 min.	High	115°F	--
6.	Sour	4 min.	Low	100°F	Sour to pH of 5.5-6.5

Do not overload the washer. Fabric should float freely. Use nonionic (synthetic) detergent. Do not use bleach.

SPIN EXTRACT ONLY – Fabric requires no more than 2 to 4 minutes of spin extracting, depending on the size of the load. REMOVE IMMEDIATELY. Excessive extraction pressure can distort plastic snaps.

DRYING CYCLE – Do not overload dryer. Fabric should float freely. Tumble dry for 3 to 5 minutes on synthetic cycle; no more than 140°F. As with all polyester, excessive heat will detract from the permanent press characteristics of the fabric. In addition, high temperatures can distort plastic snaps.

DO NOT USE BLEACH!

DO NOT PROCESS WITH FLATWORK IRONER OR MECHANICAL FOLDERS!

DO NOT IRON!

FOLD/LAYOUT IMMEDIATELY!

UNSNAP EACH SNAP WHEN REMOVING FOR LAUNDERING! DO NOT PULL ON CURTAIN TO REMOVE SNAPS AS THIS COULD CAUSE TEARING OF THE MESH AND/OR FABRIC!