

Processing Procedure

ComPel® O.R. Gowns, ComPel® Drapes, ComPel MLR™ Gowns, ComPel XTR® Gowns, ComPel XTR® Drapes, ComPel® Hamper Bags, ComPel® Apparel Products, ComPel® Wrappers made from WrapPel™ fabric and other 100% Polyester Barrier Fabrics.

PROCESSING RECOMMENDATIONS

The recommendations offered below are general guidelines. The parameters used should be adjusted based on each facilities equipment, operational procedures, and experience.

- A. All products must be laundered prior to use.
- B. Barrier fabrics should be laundered separate from other hospital linen to minimize lint accumulation from other products and maximize the economics of the lightweight polyester fabric.
- C. We recommend the following washing formula. Combination washer/extractors should be loaded at approximately 70% capacity to allow adequate flow of water across surfaces of these fabrics.

OPERATION	TIME	WATER LEVEL	TEMP.	SUPPLIES
Flush	3 Min.	High	100°F/38°C	
Flush	3 Min.	High	100°F/38°C	
Break	7 Min.	Low	160°F/71°C	Detergent & Alkali Target pH 10.5
Suds	5-7 Min.	Low	160°F/71°C	Detergent
Rinse	2 Min.	High	140°F/60°C	
Rinse	2 Min.	High	120°F/49°C	
Rinse	2 Min.	High	100°F/38°C	
Rinse	2 Min.	High	90°F/32°C	
Sour	5 Min.	Low	90°F/32°C	Sour to pH of 6

- D. **CAUTION:** Aggressive solvents and rust removing agents can damage the repellency characteristics. In addition, the routine use of citrus-based oil removers can coat/build-up on synthetic fibers and negatively affect the products barrier properties. These products should not be used when processing ComPel fabrics.
- E. Thorough rinsing is essential to properly remove all surfactants. Residual surfactants can act to reduce the repellent characteristics of barrier fabrics.
- F. After washing, tumble dry at an exhaust temperature of 160°F/71°C for approximately 15-20 minutes and an appropriate cool down cycle. Heat aids in the redistribution of the repellent components throughout the fibers.

Sterilization (for surgical products): An appropriate sterilization wrap/container should be used.

- G. ComPel XTR gowns and drapes can only be steam sterilized in pre-vac cycles with a set temperature of 270°F/132°C, an exposure time of 4 minutes and dry time of at least 15 minutes. A validated sterilization cycle should be used.
- H. ComPel O.R. gowns/drapes and other 100% polyester barrier fabrics can be steam sterilized in prevacuum steam sterilization cycles with a set temperature of 270°F/132°C, an exposure time of 4 minutes and dry time of at least 15 minutes **or** a gravity steam sterilization cycle with a set temperature 250°F/121°C, an exposure time of 30 minutes and a dry time of at least 15 minutes. A validated sterilization cycle should be used.
- I. ComPel Wrappers made from WrapPel fabric can be steam sterilized in prevacuum steam sterilization cycles with a set temperature of 270°F/132°C, an exposure time of 4 minutes and dry time of at least 15 minutes **or** a gravity steam sterilization cycle with a set temperature 250°F/121°C, an exposure time of 30 minutes and a dry time of at least 15 minutes **or** an ethylene oxide “hot” hospital cycle using a 12/88 mixture, initial vacuum set point of 26 mm, pressure set point of 10.5 psig, temperature of 130°F/55°C±10, a dwell time of 120 min. and aerated for 8 hours **or** an ethylene oxide “cold” hospital cycle using a 12/88 mixture, initial vacuum set point of 26 mm, pressure set point of 10.5 psig, temperature of 100°F/38°C±10, a dwell time of 300 min. and aerated for 8 hours. A validated sterilization cycle should be used.