

Processing Procedure Polyester or Acrylic Blankets

PROCESSING REQUIREMENTS

- A. Formula: This formula is only a guideline. Alterations should be made at the discretion of the laundry professional, based on specific requirements, supplies, equipment and experience.

	OPERATION	TIME	WATER LEVEL	TEMP.	SUPPLIES PER 100 LB. LOAD
1.	Break	8 min.	High	120°F	Neutral to mild detergent, no alkali
2.	Suds	5 min.	Low	120°F	--
3.	Rinse	2 min.	High	110°F	--
4.	Rinse	2 min.	High	100°F	--
5.	Rinse	2 min.	High	90°F	--
6.	Sour	3 min.	Low	90°F	Sour to pH of 6.0

- B. Higher temperatures can be used on heavy soil. Use 4 ounces of emulsifier per 100 pounds for heavy soil.
- C. Minimize final extraction
- D. Tumble dry at moderate temperature 120°F. Use appropriate cool down cycle. Remove promptly.