STANDARD
TEXTILE

Processing Procedure
Euro Spa Pool Towels

PROCESSING REQUIREMENTS

Formula: This formula is only a guideline. Alterations should be made at the discretion of the laundry professional based on specific requirements, supplies, equipment and experience.

OPERATION	TIME	WATER LEVEL	TEMP.	SUPPLIES PER 100 LB. LOAD
1. Flush	3 min.	High	100°F	---
2. Break	10 min.	Low	160°F	8 oz. nonionic detergent & 16 oz. alkali
3. Suds	10 min.	Low	160°F	4 oz. nonionic detergent
4. Bleach	8 min.	Low	160°F	1 qt. 1% sodium hypochlorite
5. Rinse	3 min.	High	145°F	---
6. Rinse	3 min.	High	130°F	---
7. Rinse	3 min.	High	115°F	---
8. Sour/ *Softeners	5 min.	Low	100°F	Sour to pH of 5.5 - 6.5

DRYING

Tumble dry at 160°F until dry and use an appropriate cool down cycle.
Do not overdry; hems should be “slightly” damp at the end of the drying cycle.
Do not overload as the product should float freely in the dryer.

*Softeners are recommended to maintain a soft hand, avoid overuse as they can have a negative affect on the absorbency performance.

Please contact the Technical Affairs Department of Standard Textile for any additional information at 1-800-999-0400.