

Assembly & Installation Instructions

READ AND SAVE THESE INSTRUCTIONS

PC001 & PC002

CAUTION - Read instructions carefully and turn electricity off at service entrance before installing, wiring, or servicing this product.
WARNING - Do not energize electrical supply circuit to transformer until all connections have been made and tested in accordance with all applicable electric codes.
WARNING - This product contains chemicals known to the State of California to cause cancer, birth defects and /or other reproductive harm. Thoroughly wash hands after installing, handling, cleaning, or otherwise touching this product.

Kit Includes	PC001	PC002
Chime Assembly	1	2
Chime Mtg. Screw	2	4
Chime Cover	1	2
Transformer	1	1
Button	2	2
Button Mtg. Screw	4	4

- 1.- Remove Plastic Cover (1) from Chime Assembly (2).
 - 2.- Insert wiring through access hole in Chime Assembly (2).
- Note: Make certain that the arrow labeled "TOP" is pointing upward and that the chime is level.
- 3.- Attach Chime Assembly (2) to wall with Screws (3) provided.
 - 4.- Connect wires to Transformer Terminals (4) and Chime Assembly Terminals (5) as shown in wiring diagram.
 - 5.- Turn power on and test Buttons (6) to ensure that chime is operating properly. The chime should sound 2 notes for the front door and one note for the rear door.
 - 6.- Reinstall Plastic Cover (1) on Chime Assembly (2).

DO NOT install transformer where temperature will exceed 125°F.

DO NOT connect this chime to any power source other than the low voltage (16 Volt) transformer included.

DO NOT pinch wiring under staples or damage insulation in such a way as to cause a short circuit between wires.

DO NOT position wiring inside the chime housing so that it can touch the chime bar or plungers. Push excess wire back through wall opening.

DO NOT oil the plunger mechanisms.

