

80011-PBK INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions as you may need them a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

PRIOR TO INSTALLATION CHECK WITH LOCAL AUTHORITIES FOR LOCATION OF UTILITY LINES (GAS, ELECTRIC, WATER) IN THE AREA WHERE YOUR HOLE WILL BE DUG.

MAKE SURE ALL UNDERGROUND WIRING HAS BEEN INSTALLED ACCORDING TO LOCAL BUILDING CODES.

- 1) Dig a hole 16" in diameter. Check with local building codes for hole depth.
- 2) Layer the bottom of the hole with 4" of gravel or crushed stone. Paint the lower section of the pole that will be buried with an asphalt sealer. This will prevent the corrosion between the pole and concrete.
- 3) Place the pole in the center of the hole and feed the wire through the wireway hole. Use stakes and twine to support the pole and keep it level.
- 4) Mix and pour concrete per the manufactures instructions, and let the concrete dry completely.

INSTALLATION IS NOW COMPLETED

