STANDARD TEXTILE

Processing Procedure
Terry Robes

PROCESSING REQUIREMENTS

Formula: This formula is only a guideline. Alterations should be made at the discretion of the laundry professional based on specific requirements, supplies, equipment and experience.

	OPERATION	TIME	WATER LEVEL	TEMP.	SUPPLIES PER 100 LB. LOAD
1.	Flush	3 min.	High	100°F	--
2.	Break/Suds	8-12 min.	Low	160°F	8 oz. Nonionic detergent 8 oz. Alkali
3.	Bleach	6 min.	Low	150°F	2 qt. 1% Sodium Hypochlorite*****
4.	Rinse	2 min.	High	135°F	--
5.	Rinse	2 min.	High	120°F	--
6.	Rinse	2 min.	High	105°F	--
7.	Sour/Softener	5 min.	Low	90°F	Sour to a pH of 5.5-6.5 6 oz. Softener

DRYING
After washing, tumble dry at a maximum temperature of 160°F. Do not over dry.

CAUTION
To prevent tangling, remove or securely tie belts.

***** The use of chlorine bleach must be carefully controlled and completely rinsed from these items to ensure the long-term colorfastness of colored robes. Peroxide bleaching or the use of an anti-chlor is recommended for situations that require “safer” processing because of control limitations.

Mild bleaching of white robes is recommended to maintain white appearance.