

### IMPORTANT:

Before you begin, make sure you familiarize yourself with all the parts and fully read the instructions.

### CUSTOMER SERVICE:

Toll-free customer help line available weekdays between 7:00am and 6:00pm Central Time at 800-463-0660.

### TOOLS NECESSARY:



NOTE: If screw gun has a clutch, set to lowest setting so as not to over tighten and/or strip screws.

1



**Face Frame Application:** Measure the overlay of adjoining cabinet stile to determine scribe rail thickness (not included). Rail thickness = Measurement + 1/4".  
**Frameless Application:** Recommended scribe rail thickness is 1/4".

2



Install upper and lower scribe rails to the filler pullout using small finish nails or brads (not included). Upper and lower scribe rail is attached to the outside frame rail of the pullout as shown.

3



Mount pullout filler to adjacent cabinet installing screws into the frontmost holes on the top and bottom of filler's frame.

4



**To ensure proper closing of the unit the rear of the filler may need to be adjusted.** Extend the pullout so that the front is flush with the face frame or front of adjacent cabinet. If the filler front is not even from top to bottom, press down or pull up on the rear of the filler to make the filler front and face frame even. Install screws into rear mounting holes at this time. **NOTE: Install remaining cabinetry, face frame, and/or door front (not provided).**