



Quality Gloves Since 1975

HANGTAG ASSEMBLY INSTRUCTIONS - ZIP-TIE APPLICATION (1 PAIR)

STEP 1:



Bend the bridge of the hangtag at both creases. Place the black hook through the hole in the bridge, with the “Kinco” logo facing the front of the hangtag.

STEP 2:



From inside of the hangtag, insert the zip-tie through the left-side hole of black hook and hangtag (these holes should align).

STEP 3:



Insert the zip-tie through the pull tab loop of the left-hand glove (palm facing the tag), and then insert it back through the right-side hole of the hangtag and black hook.

STEP 4:



Place the right-hand glove palm down and insert the zip-tie through the pull-tab loop, and and tighten and secure the zip-tie by pulling it through the end piece attaching all elements together.

STEP 5:



Trim off the excess zip-tie material using scissors. Caution: Do not trim zip-tie too close to the end piece.

If required, plastic pin the front of the hangtag to the top of the glove and attach vanity tags.

FINISHED ASSEMBLY



Front view

Side view

Back view