

MIRROR JOLIET BAR CART

ASSEMBLY INSTRUCTIONS

FIRSTIME & CO.®
— AMERICAN DESIGNED —

PARTS	STEP 1 Attach bottom tray (A) to panel (C).	STEP 2 Attach panel (B) to bottom tray (A).	STEP 3 Attach top tray (A) to panels (B+C).
A 2 PC			
B 1 PC			
C 1 PC			
D 2 PC			
E 3 PC			
F 1 PC			
G 16 PC			
H 8 PC			
I 1 PC	J 1 PC		

NOTE: Cap nuts (G) will be attached to the bottom of both shelves (A). Please remove before assembly.