

MONDRIAN STORAGE CABINET

Thank you for choosing this quality product. Be sure to check all packaging materials carefully for small parts that may have become loose during shipment and place all parts on a non-abrasive surface.

IMPORTANT: These parts can be cumbersome and heavy to some people, therefore the assistance of two or more people is recommended in order to prevent personal injury and insure the furniture is not damaged during the assembly Process.

PART LIST

- A. [1] TOP
- B. [2] SIDE LEGS
- C. [1] MIDLE LEG
- D. [1] SHELF PANEL

INSTRUCTIONS

- Open all the doors and remove all the removable shelf panels
 (D) out of the top (A). Close all the doors. Lay the top on a flat surface.
- 2. Attach the legs (B)/(C) to the top (A). Align and insert Allen bolt (1), lock washer (2) and flat washer (3), Tighten all the bolts by using Allen wrench (4) . See **FIGURE 01A-B**.

3. Turn the sideboard into upright position.

HARDWARE LIST

NO	DESCRIPTION		QTY
1		ALLEN BOLT	16
2		LOCK WASHER	16
3	0	FLAT WASHER	16
4		ALLEN WRENCH	1
5		SHELF PIN	16

