

Palette

QUICK-REPAIR PUTTY

USE & CARE INSTRUCTIONS

1


Surface area should be clean and free of debris.

2


Identify the color that best matches your repair. Use alone or mix colors to ensure a perfect flooring match.

3


Knead the tube thoroughly for at least 20 seconds before use.

4


Cut tip to desired bead size and apply the filler evenly.

5


Use a putty knife to distribute into gaps, nicks and scratches.

6


Wipe off excess with a damp rag. Do not allow excess filler to dry onto surrounding flooring.

7


Allow to dry for 30 minutes.

Scan here for
PRODUCT
INFORMATION



Gray
PC7728

Light Gray
PC7733

Dark Brown
PC7732

Brown
PC7725

Tan
PC7730

Light Wood
PC7726

Greige
PC7740

Natural
PC7741

Black
PC7743

White
PC7742