

# **Palette**

**QUICK-REPAIR PUTTY**

## **USE & CARE INSTRUCTIONS**

- Surface area should be clean and free of debris
- Identify the color that best matches your repair
- Knead the tube thoroughly for at least 20 seconds before use



Cut tip to desired bead size  
and apply the filler evenly



Use a putty knife to distribute  
into gaps, nicks and scratches

- Wipe off excess with a damp rag
- Do not allow excess filler to dry onto surrounding flooring
- Allow to dry for at least 1 hour

**Gray**  
PC7728

**Dark Brown**  
PC7732

**Brown**  
PC7725

**Tan**  
PC7730

**Greige**  
PC7740

**Natural**  
PC7741

**Black**  
PC7743

**White**  
PC7742