INSTRUCTION MANUAL




Laguna 47" Round Dining Table SKU:OP8004

(!) NOTICE


Do not overtighten screws. (Insert all screws before tighten screws.)

- · Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- · Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.
- Please adjust the speed slowly when you use electric drill for assembling to avoid screw slippage.






PARTS



PRODUCT ASSEMBLY-OVERALL VIEW




Look at following overall view of this table and exact position of each parts to be assembled




PRODUCT ASSEMBLY



Attach part B Table Bottom Feet to part C Table Leg with 8 pcs of Hardwarel Bolt.




Attach part C Table Leg to part A Table Top with 8 pcs of Hardware $\,$ 2 Bolt, 4 Nut and 5 Washer



3

Attach part D Side Rail to part C Table Leg with 8 pcs of Hardware 3 Bolt.



Check and tighten all the bolts and screws again and finish the assembly.

Remark: Please remove the umbrella hole cover when you insert the umbrella!

