



OUTDOOR ADIRONDACK CHAIR WITH OTTOMAN AND SIDE TABLE 3-PIECE SET

THANK YOU!

We appreciate you for choosing WestinTrends!

Thank you for letting WestinTrends continue to offer accessible luxury trends, inspired by everyone!

JOIN THE WESTINTRENDS COMMUNITY

Sign up here:

https://westintrends.com/welcome



OUESTIONS OR COMMENTS?

If you have questions reach out to cs@westintrends.com

FOLLOW, SHARE, & LEARN













PRODUCT REGISTRATION

https://westintrends.com/apps/product-registration



TABLE OF CONTENTS

ASSEMBLY INSTRUCTIONS

Outdoor Adirondack Chair	4
Round 18" Side Table	9





OUTDOOR ADIRONDACK CHAIR

! CARE & MAINTENANCE

Do not overtighten bolts. (Insert all bolts before tightening bolts.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.

TOOLS REQUIRED











HARDWARE
















PARTS







PARTS




PRODUCT ASSEMBLY - OVERALL VIEW

1 PC

Look at following overall view of this chair and learn the exact position of each part to be assembled.

1 PC




PRODUCT ASSEMBLY



Attach Part F Left Chair Leg to Part A Chair Seat with 3 pcs of Hardware #2 Bolt, Hardware #6 Washer and Hardware #5 Nut. Do the same to Part E Right Chair Leg and Part A Chair Seat.


Attach Part H Front Rail to two chair legs with 2 pcs of Hardware #4 Bolt.



2

Attach Part C Right Chair Arm to Part E Right Chair Leg with 1pc of Hardware #2 Bolt, Hardware #6 Washer and Hardware #5 Nut.


Do the same to attach Part D Left Chair Arm to Part F Left Chair Leg.






Attach Part B Chair Backrest to Part C Right Chair Arm and Part D Left Chair Arm with 2 pcs of Hardware #1 Bolt.

Attach Part B Chair Backrest to Part A Chair Seat with 2 pcs of Hardware #3 Bolt.






Attach **Part G Back Rail** between rear legs of **Part A Chair Seat** with 2 pcs of **Hardware #4 Bolt**. Check and tighten all the bolts and screws again to finish the assembly.







ROUND 18" SIDE TABLE

(!) NOTICE

Do not overtighten bolts. (Insert all bolts before tightening bolts.)

- Please do not exceed the weight limitations of this item.
- Do not stand on or use any part of this item as a step ladder.
- Firmly secure all bolts, screws and nuts before use.
- Reconfirm that all bolts, screws, and nuts are secure every 90 days.
- Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- Be aware that some parts are heavy and have sharp edges.

TOOLS REQUIRED










HARDWARE





PARTS








PRODUCT ASSEMBLY - OVERALL VIEW


Look at following overall view of this table and learn the exact position of each part to be assembled.



PRODUCT ASSEMBLY




Attach **Part C Cross Feet** to 2 pcs of **Part B Table Leg** with 2 pcs of **Hardware #1 Bolt** as shown below.






Attach **Part C Cross Feet** to 2 pcs of **Part B Table Leg** with 2 pcs of **Hardware #1 Bolt** as shown below.





Cross the parts from step 1 and step 2, then attach 4 pcs of Part B Table Leg to Part A Table Top with 4 pcs of Hardware #1 Bolt.

Check and tighten all the bolts and screws again to finish the assembly.



REGISTRATION & REFUND POLICY

https://westintrends.com/apps/product-registration



https://westintrends.com/policies/refund-policy



HAVING TROUBLE

Not sure how to assemble or missing pieces?
Please contact our Customer Service Team for assistance at cs@westintrends.com

Have Order #, Part # or SKU ready to speed up customer service!

CLEANING TIPS

REGULAR CLEAN: Use a mixture of warm water and mild soap. Gently scrub the surface with a soft bristle brush to remove any dirt or stains.

QUICK CLEAN: You can simply wipe down the HDPE furniture with a damp cloth. The material's resilience makes it resistant to most spills and stains, ensuring a hassle-free maintenance routine.

Regular cleaning not only preserves the aesthetic appeal of your furniture but also helps extend its lifespan.

Pressure washer can be used for seriously deep-cleaning - DO NOT exceed 1500 PSI - this will remove any debris and dirt.