



## GRIP 2010, 2011 PENCILS



- Grip 2010 Pencils come equipped with 0.5mm (B) standard lead.
- Grip 2011 Pencils come equipped with 0.7mm (B) standard lead.

1. Remove the eraser cap (3) from the barrel (1) by gently pulling the cap (3) off gently.
2. Remove the eraser holder (2) from the barrel (1) by firmly pulling the eraser holder (2) out.
3. Insert new Faber-Castell leads (4) 0.5mm for Grip 2010; 0.7mm for Grip 2011 into the back end of the barrel (1). Add no more than 5 leads. If more leads are used this may cause a jam.
4. Return the eraser holder (2) to the barrel (1) by firmly pushing the eraser holder (2) back into place.
5. Return the eraser cap (3) to the barrel (1) by firmly pushing the eraser cap (3) back into place.
6. To advance the lead, push down on the eraser cap (3) and begin writing.
7. To retract the lead, push down on the eraser cap (3). Push the lead back into the front piece (1) while the eraser cap (3) is held in place.

**Refills** Eraser: #131597 on Blister Card  
 Lead: Grip 2010 - **0.5mm** (B) Standard #120501  
 Other degrees of lead hardness also available (2B, HB, H, 2H, F)  
 Grip 2011 - **0.7mm** (B) Standard #122298 1pk on Blister Card  
 Other degrees of lead hardness also available (2B, HB, H, 2H)