

ASSEMBLY INSTRUCTION

ITEM: 6123-75906B-89 Display Cabinet Base 6123-75906T-89 Display Cabinet Top

6123-75906T-89 Display Cabinet Top Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.

| HARDWARE PACK | | | | |
|---------------|---------|----------------|-------------|-------|
| NO. | DRAWING | DESCRIPTION | SIZE | Q'TY |
| Α | | Allen Wrench | 69*27.2*4mm | 1 PC |
| В | | Bolt | 1/4*25mm | 4 PCS |
| С | 0 | Lock Washer | 1/4(6mm) | 4 PCS |
| D | 0 | Flat Washer | 1/4*16mm | 4 PCS |
| Е | 1 | Bolt | 8#*11/4 | 2 PCS |
| F | | Plastic Anchor | | 2 PCS |
| G | Ø. | Anti - Tip Kit | | 1 PC |

| PARTS LIST | | | | | | |
|------------|---------|--------------|-------|--|--|--|
| NO. | DRAWING | DESCRIPTION | Q'TY | | | |
| 1 | Ű | Cabinet Top | 1 PC | | | |
| 2 | | Cabinet Base | 1 PC | | | |
| 3 | | Glass Shelf | 2 PCS | | | |

Assembly steps for connecting Cabinet Base and Top:

Place cabinet top (1) on top of cabinet base (2), then secure them via mending plates (H) by using bolts (B), lock washers (C), flat washers (D) and allen wrench (A).



Note: Anti-tip kit restraint is provided.


Please follow the instructions enclosed with the pack.

HF HOOKER ASSEMBLY INSTRUCTION

ITEM: 6123-75906B-89 Display Cabinet Base

6123-75906T-89 Display Cabinet Top Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.



Note: Anti-tip kit restraint is provided.

Please follow the instructions enclosed with the pack.