

PARTS LIST


Key	Qty	Description
1	1	TOP LID
2	1	LOGO PLATE
3	1	HANDLE, TOP LID
4	1	HARDWARE F/ TOP LID ASSEMBLY
5	2	RUBBER BUMPER, RECTANGLE, F/ TOP LID
6	4	RUBBER BUMPER, ROUND
7	1	FIREBOX
8	1	VALVE ASSEMBLY
9	3	MAIN BURNER
10	1	ELECTRODE SET, F/ MAIN BURNER, 900MM WIRE
11	2	ELECTRODE SET, F/ MAIN BURNER, 600MM WIRE
12	2	CARRYOVER TUBE
13	1	MAIN CONTROL PANEL
14	1	IGNITER SWITCH MODULE
15	4	CONTROL KNOB
16	1	MATCH HOLDER
17	3	THERMOMETER
18	1	WARMING RACK
19	3	HEAT TENT
20	3	COOKING GRATE
21	1	LEFT CART PANEL
22	1	RIGHT CART PANEL
23	1	BOTTOM SHELF
24	2	CASTER, LOCKING
25	2	CASTER, FIXED
26	1	RIGHT SIDE SHELF
27	1	CONTROL PANEL, RIGHT SIDE SHELF
28	1	HOT PLATE SHELF
29	1	DRIP PAN, F/ HOT PLATE
30	1	LID, F/ HOT PLATE
31	1	CONTROL PANEL F/ HOT PLATE SHELF
32	1	LOWER REAR CART PANEL

Key	Qty	Description
33	1	UPPER REAR CART PANEL
34	1	LEFT RAIL, F/ GREASE TRAY
35	1	RIGHT RAIL, F/ GREASE TRAY
36	1	HEAT SHIELD, F/ TANK
37	1	GREASE TRAY
38	1	UPPER DOOR BRACE
39	1	DOOR, LEFT, NO HANDLE
40	2	HANDLE F/ DOOR
41	1	DOOR, RIGHT, NO HANDLE
42	1	HOT PLATE BURNER
43	1	ELECTRODE, F/ HOT PLATE
44	1	ELECTRONIC IGNITION MODULE
45	1	CAP, F/ ELECTRONIC IGNITION MODULE
46	1	IGNITOR WIRE, F/ HOT PLATE
47	1	GRATE, F/ HOT PLATE
48	1	GROMMET
49	3	COOKING GRATE, INFRARED EMITTER
50	1	REGULATOR, (COUNTRY SPECIFIC, IF SUPPLIED)
NOT Pictured		
...	1	CASTER PIN
...	2	DOOR MAGNET
...	1	HARDWARE PACK
...	1	OPERATION AND ASSEMBLY MANUAL, EUROPEAN
...	1	IR CLEANING TOOL

NOTE: Some grill parts shown in the assembly steps may differ slightly in appearance from those on your particular grill model. However, the method of assembly remains the same.

PARTS DIAGRAM

For Models 468100315, 468100415, 468600315



PARTS DIAGRAM

For Models 468200315, 468200415, 468500315, 468202415

