

Solar Wind Chime

Assembly Instructions

Note: Solar wind chime will vary depending on the item purchased.

Step 1: Remove the solar wind chime from plastic cover.

Step 2: Hang it on your patio, porch, tree or anywhere you wish.





FOR DECORATIVE USE IN THE GARDEN. NOT TO BE GIVEN TO CHILDREN AS TOY. © 2019 Exhart - Chatsworth, CA 91311. Made in China / Fabrique en Chine. All Rights Reserved. For help please call 1-(800) 775-5503

www.exhart.com



Solar Wind Chime

Assembly Instructions

Note: Solar wind chime will vary depending on the item purchased.

Step 1: Remove the solar wind chime from plastic cover.

Step 2: Hang it on your patio, porch, tree or anywhere you wish.



