



FINISH® POWERBALL®

Dishwasher Detergent Tablets

Finish® All In 1 dishwasher detergent tablets give you an amazing clean and shine - which means you will never have to re-wash your dishes again. Our Powerball® supercharges the tablet, bursting into action to scrub away the toughest food residues like dried-on food, such as lasagna and oatmeal. Our powerful cleaners remove even the toughest stains, like coffee & tea, and gently scrub your dishes & glasses sparkling clean. All In 1 tablets (individually wrapped and pre-measured) are safe for septic systems.

Features & Benefits

- World's #1 Recommended Brand* (*Recommended by more dishwasher brands worldwide)
- No need to pre-soak or pre-rinse with Powerball® as it cuts through grease
- Finish® Powerball® Tabs are 3X concentrated cleaning power of regular Finish® powder
- Removes tough stains like tea & coffee
- Easy-to-use, pre-measured dishwasher tablets with clean, fresh scent





FINISH® POWERBALL®

Dishwasher Detergent Tablets

Use Instructions

- Remove one tablet from its protective wrapper. Place the unwrapped tablet in the main dishwasher detergent dispenser and close.

Technical data	FINISH® POWERBALL® Dishwasher Detergent Tablets
Color/Form	White & Blue, Solid
pH	9.6 to 10
Shelf Life	2 Years

Product	Pack size	Dilution	Product code
FINISH® POWERBALL® - Fresh Scent	4 x 94 count	Ready-to-use	CB973306 

Safe handling

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use; and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDS are available online at www.diversey.com or by calling 888.352.2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate.