

SUPPLEMENTAL ASSEMBLY INSTRUCTIONS

REPLACEMENT FOR ASSEMBLY-PARTS LIST, PLEASE REFER TO
ASSEMBLY DETAILS AS FOLLOWING

CREAM

MUJ49UCRHA

SB [1] S216912
PL [2] S216939
BC [2] S216921
BV [2] S216940
SC [2] S216923
SV [2] S216941

MUM29SCRHA

CH [1] S216946
BF [1] S216947
PL [1] S216939
BU [1] S216929
BK [1] S216944
SU [1] S216931
SK [1] S216945
FT [4] H202410

MUN31BCRHA

WG [1] S216951
LB [1] S216948
RB [1] S216949
WS [1] S216950
FT [4] H202411

MUJ61UCRHA

SB [1] S216915
PL [2] S216939
BC [2] S216925
BV [2] S216942
SC [2] S216927
SV [2] S216943

MUM29BCRHA

CH [1] S216946
BF [1] S216947
PL [1] S216939
BU [1] S216929
BK [1] S216944
SU [1] S216931
SK [1] S216945
FT [4] H202411

MUN31SCRHA

WG [1] S216951
LB [1] S216948
RB [1] S216949
WS [1] S216950
FT [4] H202410

MUJ73UCRHA

SB [1] S216918
PL [2] S216939
BC [3] S216921
BV [3] S216940
SC [3] S216923
SV [3] S216941

CVG12BCRHA

RA [1] S216909
LA [1] S216910
FT [4] H202411

SNG12SCRHA

RA [1] S216903
LA [1] S216904
FT [4] H202410



NEED HELP?

Call 1-800-950-4782

www.bushfurniture.com