


INSTRUCTIONS FOR HANDLE FITS MOEN® SINGLE-HANDLE LAVATORY


English

Note: Your faucet may not match illustration.


1. Turn water off to faucet.
2. Remove decorative cap (A) by prying it off carefully using a small tool.



3. Unthread screw (B) to remove handle (C).



4. With spacer ring (D) in place, replace with new handle.
5. Turn on water to faucet, check for leaks.




INSTRUCCIONES PARA EL AJUSTE DEL MANGO MOEN® PARA LAVABOS DE UNA SOLA MANIJA


Español

Nota: Es posible que su grifo no coincida con la ilustración.

1. Cierre el agua del grifo.
2. Retire la tapa decorativa (A) haciendo palanca con cuidado con una herramienta pequeña.



3. Desenrosque el tornillo (B) para quitar la manija (C).



4. Con el anillo espaciador (D) en su lugar, reemplace con una manija nueva.
5. Abra el grifo del agua y verifique que no haya fugas.

