


HOMESPUN ARTIFICIAL EVERGREEN TREE

LSR-671

Read instructions carefully and follow the care instructions. Save this document for future reference.
Save the box to store the tree.



SHAPING

The fullness of your tree will depend upon the amount of time spent shaping it. The more time spent shaping the tree, the more realistic it will look. "Fluff" the branches and tips starting from the bottom.

Start with tips closest to the pole. Gently pull the individual tips upward and outward in a staggered pattern; one to the right, one to the left, one to the center. Stagger the tips, so they offset from the previous tips.

Curling some of the tips slightly upward is recommended to give the best support for hanging decorations.

Shape the top section in a smooth slope, as it would look on a real evergreen tree.

After shaping the entire tree, step back to see if any branches or tips need to be reshaped to help fill gaps. Decorations will also help fill slight gaps. Decorations are not included.

STORAGE

1. Remove all decorations.
2. Place the unit in the original box and tape it shut.
3. Store in a cool, dry place away from sunlight. Note, exposure to excessive heat or humidity may damage the tree.

! SAFETY STATEMENTS & WARNINGS !

- For indoor use only.
- Only use on a flat, level surface.
- Keep tree a safe distance away from all heat sources such as, but not limited to, heat vents, gas or electric heaters, fireplaces, candles, etc.
- When decorating with lights, miniature or LED string lights are recommended.
 - Do not decorate with lights/decorations that become hot.
 - Never decorate with lights that have "C" size bulbs.
 - Unplug lights when leaving the house, retiring for the night, or if left unattended.
- Supervise children and pets at all times. Pulling or climbing on the tree may cause it to tip over.
- This item is not intended for permanent installation.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.