

Kitchen Sink Accessories

Kohler offers a range of kitchen sink accessories designed to complement our full range of kitchen sink, bar, and beverage faucets. Add style and convenience while reducing clutter with soap/lotion dispensers that mount beneath the counter. Reduce the risk of dishwasher water line contamination with the additional of an air gap, or fit your garbage disposal with a stylish air switch. All accessories are finish-matched to KOHLER® faucets.



Purist® soap/lotion dispenser K-35761-TT
 Purist semi-professional kitchen sink faucet K-24982-TT
 Purist beverage faucet K-24077-TT



Components®
 SOAP/LOTION DISPENSER
 3³/₁₆" height | K-28293



Artifacts®
 SOAP/LOTION DISPENSER
 4⁷/₁₆" height | K-35759



Graze®
 SOAP/LOTION DISPENSER
 3³/₁₆" height | K-35760



Purist®
 SOAP/LOTION DISPENSER
 3¹/₄" height | K-35761



Traditional
 SOAP/LOTION DISPENSER
 3⁵/₁₆" height | K-35762



Transitional
 SOAP/LOTION DISPENSER
 3³/₁₆" height | K-26099



Traditional
 GARBAGE DISPOSAL AIR SWITCH
 Kit | K-35723
 Button Only | K-35725



Contemporary
 GARBAGE DISPOSAL AIR SWITCH
 Kit | K-35724
 Button Only | K-35726



Transitional
 AIR GAP
 Kit | K-9110
 Cover Only | K-9111



Contemporary
 AIR GAP
 Kit | K-35713
 Cover Only | K-35714