

Scotch-Brite™

Quick Clean Griddle Liquid 700 and 701

Technical Data



This product meets the Green Seal™ standard for Specialty Cleaning Products for Industrial and Institutional Use, GS-53, by avoiding ingredients that are toxic or harmful to humans and the environment and efficient use of packaging material.

May 2013

Description:

The Scotch-Brite™ Quick Clean Griddle Liquid is a ready-to-use food service griddle cleaning liquid intended for use with the Scotch-Brite™ Quick Clean Griddle Cleaning System. The system includes:

- Scotch-Brite™ Quick Clean Griddle Liquid 700-40 (pre-measured packets) or Scotch-Brite™ Quick Clean Griddle Liquid 701 (Quart bottles)
- Scotch-Brite™ Quick Clean Heavy Duty Griddle Pad 746
- Scotch-Brite™ Multi-Purpose Pad Holder 405-R
- Scotch-Brite™ Squeegee 410

Special Features:

- Effectively removes baked-on food and cooking oil from griddles.
- No rinse necessary.
- All chemical components are G. R. A. S. listed ("Generally Recognized as Safe" as compiled by FDA).
- Designed for use on medium-hot griddles (300 - 350°F.)—saves cool-down time.
- Does not contain caustic soda or caustic potash.

Applications:

The Scotch-Brite™ Quick Clean Griddle Liquid is used to remove baked-on food from hot griddles.

Check your manufacture's warranty on your griddle before using.

*** For Chromium-plated or mirror-finish griddles use The Scotch-Brite™ All Purpose Scouring Pad 9488R in place of the Scotch-Brite™ Quick**

Clean Heavy Duty Griddle Pad 746.

Packaging:

700-40: 3.2 fl. oz. per packet, 40 packets per case

701: 1 quart (32 fl. oz.) per bottle, 4 bottles per case

General Use Directions:

1. Scrape the griddle with a spatula to remove loose food debris.
2. Attach Scotch-Brite™ Quick Clean Heavy Duty Pad 746* to Scotch-Brite™ Multi Purpose Pad Holder 405-R.
3. Pour 2 to 4 ounces (depends on size of griddle) of the liquid evenly over medium-hot griddle (300-350°F or 149-177°C).
4. Immediately spread liquid around the griddle using the Scotch-Brite™ Quick Clean Heavy Duty Griddle Pad 746* on the Scotch-Brite™ Multi Purpose Pad Holder 405-R. Use moderate pressure to scour away burnt-on food soil.
5. Move liquid into the grease trap using the Scotch-Brite™ Squeegee 410.
6. For heavily soiled griddles, you may need additional liquid. Repeat step 2- 5 if necessary.
7. Turn the griddle off. Wipe down the surface using a thick, wet cloth. To avoid contact with steam, move the wet cloth using the long-handled Scotch-Brite™ Multi Purpose Pad Holder 405-R.
8. Season griddle with a thin coating of cooking oil. Wipe off excess oil with a dry cloth.
9. Thoroughly rinse pad, pad holder and squeegee. Apply

new pad after 3-4 cleanings or when pad is no longer effective at scouring.

Improper use may result in altered product performance and may increase the risk of health effects.

Coverage:

2 to 4 ounces per application, depending upon the griddle size.

Storage:

Store above 40°F or 4°C.

Troubleshooting Guide:

Refer to troubleshooting guide below.

Personal Protection Equipment (PPE)

Recommendation:

Avoid eye and skin contact, avoid skin contact with material. Safety glasses and gloves are recommended. Refer to MSDS for detailed PPE guidance.

Waste Disposal Method:

Incinerate unused product in an industrial or commercial facility in the presence of a combustible material. As a disposal alternative, discharge small quantities of less than 5 gallons (20 liters) to a municipal or industrial waste water treatment system. Rinse empty quart container with water and recycle (No. 2 HDPE), or dispose of empty pouch in trash.

Precautionary Summary:

- Refer to product Material Safety Data Sheet (MSDS 09-2779-8) for specific health hazards, first aid and precautionary information.

KEEP OUT OF THE REACH OF CHILDREN.

Troubleshooting Guide

Problem

Streaking, white haze or brown haze after cleaning.

Cause

Griddle is too hot.

Solution

Repeat the wipe down with a very wet towel using the long-handled Scotch-Brite™ Multi Purpose Pad Holder 405-R to move the towel.

Seasoning oil turns brown on the griddle after cleaning.

Time between using the squeegee and wipe down is too long.

Remove the darkened oil with a wet terrycloth towel held with long-handled Scotch-Brite™ Multi Purpose Pad Holder 405-R, then season the griddle with fresh oil using a clean Scotch-Brite™ Quick Clean Heavy Duty Griddle Pad 746* to spread oil evenly.

Food sticks after cleaning.

Griddle not properly seasoned.

a) Season the griddle with 2 to 4 ounces of cooking or frying oil spreading evenly over the entire griddle using a clean Scotch-Brite™ Quick Clean Heavy Duty Pad 746* and the Scotch-Brite™ Multi Purpose Pad Holder 405-R.

b) If the griddle is to be put into service immediately, season at 300-350°F and let the oil penetrate into the highly cleaned griddle before starting to cook again.

c) If the griddle is to be left overnight after cleaning and seasoning, make sure the oil penetrates while the griddle is hot, then cool down.

Premature wear or degradation of the Scotch-Brite™ Quick Clean Heavy Duty Griddle Pad 746.

Griddle is too hot.

a) The Scotch-Brite™ Quick Clean Heavy Duty Griddle Pad 746* is designed to be used at temperatures not to exceed 350°F.

b) Always clean the griddle at temperatures between 300-350°F.

c) A surface temperature thermometer is recommended to verify that the temperature range use as needed.

3M Branch Sales Offices

ANCHORAGE

11151 Calaska Circle
Anchorage, AK 99515
Telephone: 907/522-5200
Facsimile: 907/522-1645

HONOLULU

4443 Malaai Street
Honolulu, HI 96818
Mail to: P.O. Box 30048
Honolulu, HI 96820
Telephone: 808/422-2721
Facsimile: 808/422-9557

CONTINENTAL UNITED STATES

Customer Service Department
3M Center Building 223-2N-20
St. Paul, MN 55144-1000
Order Entry: 800/698-4595
Facsimile: 877/318-0220

CANADA

1840 Oxford Street East
London, Ontario, Canada
N5V 3G2
Mail to: P.O. Box 5757
London, Ontario, Canada
N6A 4T1
Telephone: 800/364-3577
Facsimile: 800/479-4453

Important Notice to User:

Technical Information: The technical information, recommendations and other statements contained in this document are based upon tests or experience that 3M believes are reliable, but the accuracy or completeness of such information is not guaranteed.

Product Use: Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. Given the variety of factors that can affect the use and performance of a 3M product, user is solely responsible for evaluating the 3M product and determining whether it is fit for a particular purpose and suitable for user's method of application.

Warranty and Limited Remedy: 3M warrants that each 3M product will be free from defects in material and manufacture for 90 days from the date of purchase from 3M's authorized distributor. 3M MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. If a 3M product does not conform to this warranty, the sole and exclusive remedy is, at 3M's option, replacement of the 3M product or refund of the purchase price.

Limitation of Liability: Except where prohibited by law, 3M will not be liable for any loss or damage arising from the 3M product, whether direct, indirect, special, incidental or consequential, regardless of the legal theory asserted.



Building and Commercial Services Division

3M Center, Bldg 223-2N-21
St. Paul, MN 55144-1000
www.3M.com/foodservice

Scotch-Brite is a trademark of 3M Company. Used under license in Canada.
Green Seal is a registered trademark of Green Seal, Inc.
©3M 2013. All rights reserved
509843